

Omnicell® VBM 200F

Automation for SureMed® adherence cards

The only automated pharmacy solution that efficiently and accurately fills and checks SureMed® adherence cards. Our new filling machine ensures pharmacies have the competitive advantage to easily scale their business to improve adherence and patient outcomes today.

Benefits for your business and patients

- improved accuracy and reduced checking time
- ability to track and trace each medication packed
- checks and verifies each drug packed
- adherence cards support patients to live better for longer - improving health outcomes
- small-footprint, ergonomic design that fits through a standard doorway
- ease of access for cleaning and maintenance
- extremely intuitive and easy-to-use interface

Integrates with **Omnicell's eMAR solution** - our award winning eMAR solution for care homes that automates the entire medication management and administration process, making it safe, simple and compliant for everyone involved. Both pharmacy and care homes can have complete traceability from the moment medications are dispensed to being administered.

Increase your pharmacy's revenue and decrease your expenses

- free up staff time and reduce your operating costs
- process up to 35-40 sealed and audited cards per hour
- assemble more packs with less resource
- supports hub and spoke model to improve efficiency and reduce costs



Compatible
with most
UK pharmacy
interfaces

Omnnicell® VBM 200F

VBM 200F features at a glance

- Multiple-medication solution
- Productivity up to 35-40 Blister Cards/per hour
- Ability to verify and track each medication dispensed
- Maximum safety, with a full dispensing audit trail
- Scalable automation solution as part of a single workflow
- Low maintenance rate, easy to clean
- Intuitive user interface
- Industry-leading vision checking system
- Holds 200 cartridges – unlimited inventory, hot swappable
- Closed loop medication management system
- Seamless active workflow
- Various cards and blister formats available
- Enhanced printing of medication information on final packing

STEP 1

Data transfer from host

Original prescription from the host system is transferred to the VBM database.

STEP 2

Cartridges with pills

The required pills for one intake time are dispensed by the cartridges.



STEP 5

Dispensing tray

Only correct intake dosages will be dropped into the proper cup in the blister tray.



STEP 4

Verification

All medicines are collected in a buffer and checked by the vision control.



STEP 3

Multifunctional Dispense Array (MDA)

Remaining medicine and/or other medication is dispensed by the MDA.



Omnicell® VBM 200F

SureMed® by Omnicell multi-medication adherence cards

Our new filling machine uses our SureMed® Class B certified, weekly pill packs which are designed to improve patient adherence by clearly organising and labelling multiple medications. Using the packs and the filling machine offers our customers and their patients numerous benefits:

- patient specific information and photo printed on the front of the card
- consolidated label printed on the inside cover of each card, including drug images
- potential to include individual pharmacy branding to the front of the card
- option available to print front and inside labels directly to the card



Consolidated label with full colour drug images and dosage instructions

Ability to include patient photo as well as details for improved safety.

Easy-to-understand, clearly marked days-of-the-week

+971565348804 | info@omnicell.com | www.omnicell.me

